

AUTOLIFT SYSTEM

INSTALLATION MANUAL FOR

ADAPTER

FAKSMERFWD

MERCEDES FWD from 2020 with
Standard rear Chassis

Step 1:

Insert the plates in the holes



Step 2:



Insert the adapter in the space present on the chassis and push most frontly possible.

Step 3:



Fit the adapter with the bolts supplied

Front Right adapter Mercedez Al-Ko

Step 1 – 2 – 3:



Follow the same procedure of the front left adapter

**JACK WITH MOTOR TO THE OUTSIDE OF THE VEHICLE AND
ROTATION REAR**



EXAMPLES OF JACKS CORRECTLY INSTALLED

JACKS WITH MOTOR TO THE OUTSIDE OF THE VEHICLE AND ROTATION REAR

Rear left adapter Mercedes 316

Step 1:



Put the adapter in the point illustrated, the rear support of the crossbow suspension Step 2:



Insert the special plates and fix the adapter with the M8 bolts supplied

3



Step 3:

4



Fix the jack.

USE THE SAME PROCEDURE FOR THE REAR
RIGHT ADAPTER

**JACKS WITH MOTOR TO THE OUTSIDE OR INSIDE OF THE
VEHICLE AND ROTATION REAR**