

## OPERATING INSTRUCTIONS

# 12V Range Hood

### General information


This suction hood has been specially designed for fitting in caravans and campers. The smoke and steam from the kitchen passes through the aluminium filter and is emitted into the air through the flue pipe.

To ensure that the hood is always working efficiently, you should occasionally check that there is nothing blocking the pipe fitted to the top or back of the hood.

### Maintenance and cleaning

Wash the hood occasionally with water and a liquid neutral detergent. Do not use solvent or abrasive products. The aluminium filter can be washed.


## Swing Flat



### Assembly Instructions

1. Open the aluminum filter
2. Fix the hood with 4 screws
3. Plug the power wire

## Sigma Flat



### Assembly Instructions

1. Make in the superior shelf the holes corresponding to the hoods attachment points
2. Connect the hood to the shelf with the screws

### CAUTION:

If the filter is not correctly looked after and cleaned, grease can build up on it and therefore cause a fire risk.

Do not cook over an open flame or use deep fryers under the hood, as the excessive heat could damage it.

### LIGHTING:

The hood can be fitted with halogen lamps or LED. To change the halogen lamp remove the metal ring that holds the glass cover in place and then remove the lamp. Do not touch the lamp with your bare hands as it could be damaged.